

HFG BondLock: Secure Box User Guide



Call us on: +44 (0)161 429 1580 Visit us at: [maplefleetservices.co.uk](https://www.maplefleetservices.co.uk)




HF Green BondLock User Guide

This vehicle is equipped with a secure box in the load compartment, protected by BondLock. Please refer to the user guide below for an overview of the system's operation.

Operating BondLock

1.

To unlock, present the RFID fob to the Maple antenna, located on the top panel of the box.



2.

BondLock will now release, allowing the door of the box to be opened. If the door is not opened within 7 seconds, the locking mechanism will re-engage.



3.

Once the door of the box is closed, the system will automatically lock.

